



**AUTEXIER**

**MANUFACTURER OF INDUSTRIAL MARINE AND OIL & GAS VALVES  
IN BRONZE AND ALUMINIUM-BRONZE**

93, rue Louis Blanc - 02300 CHAUNY - FRANCE  
Tel: +33 (0)3.23.52.02.86 - Fax: +33 (0)3.23.39.52.28  
[www.autexier.fr](http://www.autexier.fr)

## Instructions of assembly and maintenance for safety valves



**2201 and 2202**

### **I) Checking at the delivery**

Check at receipt that the packaging is in a good condition, that the delivered safety valves are in accordance with your order and that the material is not damaged.



### **II) Storage**

The safety valves can be delivered several months before use. Their performances can be corrupted if a particular care is not provided to their storage and protection.

It is recommended to store valves in clean and closed premises, protected from the bad weather and sand projections, dusts or other solid particles. Keep them as much as possible in their original packing. The obturating corks, the threading's protections, the plastic envelopes, will be removed only when the safety valve will be used. Avoid the shocks on the flanges faces and on the threading.

### **III) Assembly of the valve**

- 1) The safety valves must be handled with a special care. It is necessary to avoid the penetration of foreign bodies inside the safety valve during the assembly or the use.
- 2) To assembly, the inlet must be directed towards bottom, vertically, with the cap directed upward. In the case of a canalised safety valve, the outlet will be then in horizontal position (see picture below).



3) During assembly or maintenance, if the valve is located in an explosive area, use a material in accordance with the explosive classification of this area (ATEX 2014/34/EU), without isolating it electrically from the rest of the system to avoid any electrostatic phenomenon.

#### **IV) Instructions**

- 1) It is forbidden to neutralize the valve mechanism.
- 2) No valve must be inserted between the installation to be protected and the safety valve, neither on the circuit downstream circuit of the safety valve. Any foreign body must be present in the downstream/upstream circuit.
- 3) The valve should be installed in a place where there is no risk of shock which could damage its working.
- 4) It is necessary to eliminate any previous and post pressure before removing the valve and be sure not to create an explosive inside or outside the valve. The staff operating the setting up of the valve will be trained to perform this operation and will wear all necessary protections linked to the carried fluid.
- 5) You must respect the use conditions (pressure, temperature, fluid, counter-pressure) when you ask us to help you (no corrosive fluids or that could make wear, no unstable fluids with dangerous decomposition, do not use several fluids which could react together or release derivatives that could lead to an explosive atmosphere, no viscous fluids capable to solidify).
- 6) Do not modify the documents supplied by AUTEXIER (instructions, metal plates, certificates etc.).

**CAUTION: AUTEXIER is not anymore responsible for the good working of the valve if this one has been dismantled or modified by a person not approved by AUTEXIER.**


#### **V) Maintenance**


You must keep the valve clean and in order to work (check regularly that the escape is free, without deposits, impurities or taps in the pipes).

#### **VI) Guarantee**

All our products are guaranteed during twelve months from the delivery against any defect of material or manufacturing, when the conditions of use are respected. This guarantee is limited to the replacement or to the repair by our company of the defective recognized parts. We decline all responsibility in case of disrespect with this instruction guide.

Ref. 2201





**VII) Marking**

After being tested and adjusted, each valve is sealed by AUTEXIER. If another agency makes a mark by punching the valve should not be damaged. Poorly executed, deformations could make tap fugitive, or inoperative. Punching of thin walls is prohibited.

Valves are identified by a label with the following information:

- The date of shipment

- Specifications:

1 - Designation: Reference of safety valve

2 - Calibration certificate number or number of the linked document and number of declaration of conformity to directive 2014/68/EU

3 - Inlet nominal diameter and outlet nominal diameter (for canalized safety valves)

4 - Maximum conditions of use

5 - Envelope pressure test

6 - Safety pressure

7 - Set pressure

8 - Group of fluid G for Gas / L for Liquid or S for Steam

- If requirement, **CE** marking with identifying number of the notified agency 0094 (LRQA)

 <b>AUTEXIER</b> FABRICANT EN ROBINETTERIE INDUSTRIELLE 93 RUE LOUIS BLANC / 02300 CHAUNY FRANCE / + 33 (0)3 23 52 02 86		jj/mm/aa :	
Désignation : <b>1</b>		N° Doc. : <b>2</b>	Dcl : <b>2</b>
○	Entrée (Inlet) : DN <b>3</b>		Sortie (Outlet) : DN <b>3</b>
	PN (NP) : <b>4</b> Bar	TS (Mini./Max.) : <b>4</b> °C	
Pression d'essais (Test pressure) PT : <b>5</b> Bar			 0094
Pression maximale admissible (Safety pressure) PS : <b>6</b> Bar			
Pression de tarage (Set pressure) PDO : <b>7</b> Bar			
Groupe de fluide (Group of fluid) : <input type="text" value="1"/> → <b>8</b>			

**It is imperative to respect the conditions of use stated on the plate (pressure, temperature, and fluid) under risk of damaging the valve and void the warranty.**

AUTEXIER

We declare, under our only responsibility, that the product "safety valve", to which refers the present declaration is in accordance with the directive 2014/68/EU in the following procedures of evaluation of conformity to Module H1  
A certificate of type CE is available for the equipment of devices under pressure.

The control is established by LRQA (**CE** 0094)

