



**AUTEXIER**

**MANUFACTURER OF INDUSTRIAL MARINE AND OIL & GAS VALVES  
IN BRONZE AND ALUMINIUM-BRONZE**

93, rue Louis Blanc - 02300 CHAUNY - FRANCE  
Tel : +33 (0)3.23.52.02.86 - Fax : +33 (0)3.23.39.52.28  
[www.autexier.fr](http://www.autexier.fr)

## Instruction for use for lift vertical check valves




**113 and AU113**

### Operation

When the fluid flows in the direction of arrow stamped on the *body 1*, it tends to lift the *disk 4*. However, if the direction of the fluid flows is in the opposite direction to the direction of arrow, the *disk 4* covers its support (on *body 1*), the fluid flow is interrupted. The movement of the *disk 4* is guided by the *bonnet 2*, screwed into the *body 1*.

Ref. 113 / AU113



Document 0904DA160E version 00 of 06 Jan. 2022

